







Для моделей ЕС, ЕВ, ЕТ






A1	A2	A3	A4	A5
	A7	A8	A9	A10
A11	A12	A13	A14	A15
A16	A17		A19	A20
ST4X 40=8 ST4X1 4=8 ST4X1 2=16 ST4X1 0=4 M 4X 25=10 M 4X 16=8				







A




B




C



D



E



F

