















Для моделей ЕС,ЕВ,ЕТ






A1  X2	A2  X1	A3  X1	A4  X2	A5  X4
	A7  X1	A8  X2	A9  X8	A10  X4
A11  X2	A12  X2	A13  X1	A14  X2	A15  X1
A16  X1	A17  X1		A19  X1	A20  X2
			 ST4X40=8 ST4X14=8 ST4X12=16 ST4X10=4 M4X25=10 M4X16=8	







A




B




C



D



E



F

